




Xede Wiring Diagram – 2000 Mitsubishi Verada 3.5L V6

Wiring Details:

Note: Connectors are drawn as seen from the wire side.

XEDE Configuration:	M
XEDE Revisions:	All
XEDE Harness:	XH-WBG (Generic Harness)
Special Notes / Information:	See Diagram Over Page

ECU
View from back of connectors
(wire view)



* ONE OR BOTH OF THE CHASSIS GROUNDS MUST BE CONNECTED IF ANY OF THE FOLLOWING XEDE FEATURES ARE BEING USED:

- WATER SPRAY
- BOOST CONTROL
- AUXILIARY INJECTOR DRIVE

** Red wire in 3 core shielded cable. DO NOT terminate the shield wire in the 3 core cable

