


Xede Wiring Diagram – Toyota Hilux 4.0L V6 Standard NA or TRD Factory Fitted Supercharger Kit

Wiring Details:

Note: Connectors are drawn as seen from the wire side.

<i>XEDE</i> Configuration:	S
<i>XEDE</i> Revisions:	All
<i>XEDE</i> Harness:	XH-WBG (Generic Harness)
Special Notes / Information:	See Diagram Over Page

ECU Connector
View from back of connectors
(wire view)



* ONE OR BOTH OF THE CHASSIS GROUNDS MUST BE CONNECTED IF ANY OF THE FOLLOWING XEDE FEATURES ARE BEING USED:

- WATER SPRAY
- BOOST CONTROL
- AUXILIARY INJECTOR DRIVE

** Red wire in 3 core shielded cable. DO NOT terminate the shield wire in the 3 core cable

