



Xede Wiring Diagram – Ford BA XR6, XR8

Wiring Details:

Note: Connectors are drawn as seen from the wire side.

XEDE Configuration:	F
XEDE Revisions:	All
XEDE Harness:	XH-WBG (Generic Harness)
Special Notes / Information:	See Diagram Over Page
	<ol style="list-style-type: none">1. ECU plugs can be unplugged without removing ECU.2. Pay close attention to wastegate solenoid wiring and shielded cable wiring.3. Generic harness may have additional wiring for features that may not be used in some applications. Leave unused wires unterminated. Ensure no shorts to ground or power.

